



NOTE:

- 1) EXTEND MEMBRANE TO EXCEED ANTICIPATED ICE DAM HEIGHT
- 2) CAREFULLY POSITION MEMBRANE AT ROOF PERIMETER WHEN INSTALLING METAL DRIP EDGE
- 3) INSTALL CCW WIP IN SHINGLE FASHION  
EDGE SPLICE IS 3 1/2" MIN.  
END SPLICE IS 6" MIN.

CCW WIP-1

RAKE AND EAVE

**CARLISLE**

© 1996 CARLISLE CORPORATION