



- NOTE:
- 1) CENTER MEMBRANE OVER VALLEYS AND RIDGES
STARTING AT THE LOW POINT FOR LAPS TO SHED WATER
 - 2) AVOID FASTENERS IN VALLEY

CCW WIP-3

VALLEYS

CARLISLE

© 1996 CARLISLE CORPORATION