



- NOTE:
- 1) CUT THE CCW WIP MEMBRANE TO FIT SECURELY AROUND PENETRATION
  - 2) INSTALL FLASHING OR LEAD BOOT OVER CCW WIP DURING LAYING OF SHINGLES

CCW WIP-6

PIPE PENETRATION

**CARLISLE**

© 1996 CARLISLE CORPORATION