



NOTE:

- 1) EXTEND MEMBRANE TO EXCEED ANTICIPATED ICE DAM HEIGHT
- 2) INSTALL CCW WIP IN TRANSITION AREA FIRST, THEN COVER WITH METAL FLASHING AND SHINGLES
- 3) CCW WIP IS NOT INTENDED FOR EXPOSED FLASHING APPLICATIONS
- 4) INSTALL ROOFING SHINGLES PER MANUFACTURES INSTRUCTIONS

CCW WIP- 2

ROOF TO WALL TRANSITION

CARLISLE

© 1996 CARLISLE CORPORATION